




TI-84 Plus Silver Edition Backup Battery Replacement

This guide shows you how to replace the backup battery for the TI-84 Plus Silver Edition.

Written By: Agustin



INTRODUCTION

This guide shows you how to replace the backup battery on the TI-84 Plus Silver Edition. The backup battery is located on the back side of the calculator above the main batteries.



TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Main Battery



- Push firmly down on the tab located on the back of the calculator near the center.
- Pull the tab up, lifting it off of the calculator and exposing the batteries.

Step 2



- Push from the positive side to the negative side and pull up to remove each battery.

Step 3 — Backup Battery




- Using the Phillips #00 Screwdriver, unscrew the 15 mm screw holding the backup battery cover, located above the main battery area.

Step 4



- Grab the plate and lift gently upward, to remove the backup battery cover.

Step 5



- Wedge the small plastic opening tool under the backup battery in the gap to the left of the backup battery.
- Push gently downward until the backup battery pops out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 03:59:37 AM.